



129 Santa Fe
Alamosa, CO 81101
719-379-3839
btc@gojade.org

Connecting Your Device to a Wireless Network

This manual is designed to be a tutorial for our customers seeking to connect their electronic devices to their home Internet network. This manual will include step-by-step instructions for connecting your device(s) to the internet; if your device will not connect, please contact Blanca Networks Technical Support at (719)-589-2964.

Table of Contents

We cover the following devices in this manual. Please scroll to the page of the device you wish to connect to the Internet.


- Barnes & Noble Nook.....2
- Amazon Kindle Fire.....4
- Android.....6
- Apple iPad.....8
- Apple iPhone.....9
- Apple OS X (Mac).....10
- Windows 7.....11
- Windows 8.....12
- Windows 10.....14



There will be a time when the information in this manual is outdated. When this happens, contact your device's manufacturer (Apple, Microsoft, Sony, Google, etc.), and ask them your specific question(s).

Barnes & Noble Nook

1. Open your **Settings** screen.



2. Tap **Wireless** to go to the network information screen.



3. Toggle Wi-Fi to **ON**.
4. Select the network you want to connect to.



5. Enter your network password, then tap **connect**. This is the **Wireless key (or WPA-PSK key)** shown on the bottom of your router.



6. Tap **Connect**

Amazon Kindle Fire


1. Tap the settings icon on the top right corner of the screen.



2. Next, tap the **Wi-Fi** setting on the top of the screen. Make sure that the **Wireless Networking** option is set to ON.



3. Tap the name of your **SSID**.



4. Enter your network password, then tap connect. This is the Wireless key (or WPA-PSK key) shown on the bottom of your router.




5. Tap on the **Connect** button at the bottom of the screen.
6. Your Amazon Kindle Fire is now connected to the wireless network.

Android


1. From the **Home** menu tap the **Apps** Icon.
2. Tap the **Settings** Icon.




3. Tap **Wireless and Networks**, make sure **Wi-Fi** is turned on, then tap **Wi-Fi**.



4. Select your **Wi-Fi** network.



1. Enter your network password, then tap **connect**. This is the **Wireless key (or WPA-PSK key)** shown on the bottom of your router.



You are now connected to your wireless network.

Apple iPad

1. Tap **Settings**



2. Tap **Wi-Fi**. Wait a moment as your iPad detects the **Wi-Fi** networks in range.



3. Select your **Network Name** from the list of available networks.



4. Enter your password and select **Join**. Your password is the **Wireless key (or WPA-PSK key)** shown on the bottom of your router.



5. Wait a few seconds while your iPad connects. Once connected, a check mark will appear next to your **Network Name**.



You are now connected to your wireless network.

Apple iPhone

1. Tap **Settings**



2. Tap **Wi-Fi**. Wait a moment as your iPad detects the Wi-Fi networks in range.



3. Select your **Network Name** from the list of available networks.



4. Enter your password and select **Join**. Your password is the **Wireless key (or WPA-PSK key)** shown on the bottom of your router.



5. Wait a few seconds while your iPhone connects. Once connected, a check mark will appear next to your **Network Name**.




You are now connected to your wireless network

Apple OS X (Mac)

1. At the top right side of your screen, click the Wireless icon.



2. Select your router's **Wireless name**.



3. Enter your password into the field. Your password is the **Wireless key (or WPA-PSK key)** shown on the bottom of your router. Enter the key and click **OK**.




You are now connected to your wireless network. Open your web browser to start browsing!

Windows 7

1. On the bottom right side of your screen, left click on the wireless connection icon.



2. Find your router's **Wireless name** from the list of available wireless networks (this will usually be your last name or the name of your business) and click **Connect**.



3. Enter your **network security password** in the blank field. Your password is the **Wireless key (or WPA-PSK key)** shown on the bottom of your router.



4. Click on the **Home network**.



You're now connected to your wireless network. Open your web browser to start browsing!

Windows 8 (Tablet/PC)

1. If you are using a PC, move the mouse to the bottom or top right corner of the screen and select the cog icon labelled **Settings**. If you are using a tablet, swipe left from the **right** side of the screen and select **Settings**.



2. Select the wireless icon.



3. Select your wireless network from the list of available networks.



4. Select **Connect**.



5. Enter your wireless password and select **next** to connect. Your password is the **Wireless key (or WPA-PSK key)** shown on the bottom of your router.



6. Windows will verify the password and, if entered correctly, you will be connected to the Wireless network.



You are now connected to your wireless network. Open your web browser to start browsing!

Windows 10

1. Select the Wi-Fi icon in the taskbar. If you don't see it, you might have to tap the up arrow to make it visible.



2. Select your Wi-Fi network from the list of available networks.
3. Check the **Connect Automatically** box.
4. Select the **Connect** button.



5. Enter the Wi-Fi password and tap or click **next**. Your password is the **Wireless key (or WPA-PSK key)** shown on the bottom of your router.



You are now connected to your wireless network. Open your web browser to start browsing!